


QUICK START GUIDE 1-2-3

DataLocker K350 - Encrypted Flash Drive









1. Press the power button for 3 seconds



2. Create and confirm your admin password, follow the screen instructions

Press quickly on the number button to navigate all characters available on the button.

Example using the default configurable keypad preference (number first)

Press once	Again quickly press	Again quickly press	Again quickly press
			
→ number 2	→ letter A	→ letter B	→ letter C
			

The encircled character on the screen is input after 1 second or when you press another button.

Press the 'Backspace arrow' button to erase entries



Press the 'Enter' button to confirm your admin password



3. Connect and start working

Navigate selections by pressing the 'Up/down arrow' buttons



Confirm your selection by pressing the 'Enter' button



Go back in the menu navigation by quickly pressing the 'Backspace arrow' button, long-pressing turns the device off.



- Select **MENU** to access all settings, such as enabling a user login
- To start working with your data in a regular way confirm **CONNECT** selection and plug the drive into the host USB port as shown on the screen.



The encryption is automatic. The K350 locks when it is unplugged from the host.